

1000 SERIES PULL TRIM INSTALLATION INSTRUCTIONS

(For doors with 2 1/8" hole/161 prep requiring cylinder sleeve)

DFP-03NL, DFP-02DT

NOTE:
Backset of 2 7/16" from jamb to center or 2 3/4" from door edge to center is acceptable.
Strike shim can be used or not used to make adjustments to the roller strikes projection to compensate for doors with different backsets.

