

FOR 2000R & F2000R USE

FOR 2000V & F2000V USE

TEMPLATE(C)

Fold on dotted line and fit on door edge

3 9/32"

(1.) 1/4" x 6 (FOR 2000V USE)

(2.) For F2000V(Fire Rated)-Drill 9/32" holes inside and 3/8"holes outside for the (6) thru bolts.

