



Note: Dimensions shown in brackets [] are in millimeters.

Strike location on frames must be adjusted for thickness of door silencers when used

<p>Template No. ASA.MTL</p>	<p>Design Hardware Frame Template</p> <p>4 7/8" ASA Strike</p>	
--------------------------------------	--	--