



1. Mount approximately 54" above floor or per specified ada.
2. Mark and mount Arm Base to door frame. Note: Position base so that base edge is $1/8$ " from edge of frame.
3. Position and mount base on door $7/16$ " from edge of arm base.

