

EDT6-DFP Trim for 1000 Series 161 Prep Installation Instructions

(For doors with 2 1/8" hole/161 prep requiring cylinder sleeve)

NOTE:
Backset of 2 7/16" from jamb to center or 2 3/4" from door edge to center is acceptable. Strike shim can be used or not used to make adjustments to the roller strikes projection to compensate for doors with different backsets.

DFP-03NL, DFP- 02DT

