

2000 SERIES THUMBPIECE TRIM INSTALLATION INSTRUCTIONS

TP-08, ENTRY
TP-02DT, DUMMY

NOTE:
Backset of 2 7/16" from jamb to center or 2 3/4" from door edge to center is acceptable. Strike shim can be used or not used to make adjustments to the roller strikes projection to compensate for doors with different backsets.

