

116 SERIES HEAVY DUTY ARM



Specification

Base Material: Forged solid steel

Application: Ideal for use in high abuse areas

Controls: Removable Auxiliary Stop

Handing: Non-handed

Mounting: Parallel Arm only

Duty: Ideal for high abuse applications

Accessories: Fifth Hole Spacer included
Spring Stop available separately as replacement for auxiliary stop
Shoe Supports & Blade Stop Spacers available separately

Fasteners: Machine, wood and self tapping machine screws

Warranty: Limited lifetime warranty

