

# MORTISE FUNCTION CHANGE INSTRUCTIONS

## DESIGN HARDWARE M SERIES ELECTRIC MORTISE LOCK

TO CHANGE THE LOCKING FUNCTION FOLLOW THE INSTRUCTIONS BELOW CAREFULLY.

STEP 1: REMOVE THE 4 COVER SCREWS AND COVER.

STEP 2: USE THE ILLUSTRATION BELOW FOR SWITCHING LOCK FUNCTION.

