

416 SERIES DOOR CLOSER ACCESSORIES



Heavy Duty & Hold Open Arms



416 Series Heavy Duty Arm



416 Series HD Hold Open Arm



416 Adjustable Type Hold Open Arm



416 Friction Type Hold Open Arm

Drop Plates & Cover



416 Regular Drop Plate



416 TJ-1 Drop Down TJ Drop Plate



416 Parallel Arm Drop Plate



416 TJ-2 Center Mount TJ Drop Plate

Parts & Accessories



416 Extended Arm



416 Extra Long Extended Arm



Spring Stop For use with 416 Heavy Duty Arm & HD Hold Open Arm



416 Blade Stop Spacer



416 Shoe Support